



TANGO
Device
Server

Booster Sequence Start User's Guide

RF_PLCBOO Class

**Revision: release_1_0_0 - Author: elattaoui
Implemented in C++**

Introduction:

This class starts the booster sequence and switch(on/off) the local test mode

Class Inheritance:

- Tango::Device_3Impl
 - RF_PLCBOO

Properties:

Device Properties

Property name	Property type	Description
Url	Tango::DEV_STRING	The PLC Server name

Device Properties Default Values:

Property Name	Default Values
Url	No default value

There is no Class properties.

Attributes:

Scalar Attributes

Attribute name	Data Type	R/W Type	Expert
startRFBoo : Di½marrage de la si½quence RF_BOO	DEV_BOOLEAN	READ_WRITE	No
stopRFBoo : Arret de la si½quence RF_BOO	DEV_BOOLEAN	READ_WRITE	No
localTestMode : Test sur charge	DEV_BOOLEAN	READ_WRITE	No

Commands:

More Details on commands....

Device Commands for Operator Level

Command name	Argument In	Argument Out
Init	DEV_VOID	DEV_VOID
State	DEV_VOID	DEV_STATE
Status	DEV_VOID	CONST_DEV_STRING

1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection. After an Init command executed on a device, it is not necessary for client to re-connect to the device. This command first calls the device *delete_device()* method and then execute its *init_device()* method. For C++ device server, all the memory allocated in the *nit_device()* method must be freed in the *delete_device()* method. The language device desctructor automatically calls the *delete_device()* method.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_VOID : none.
- **Command allowed for:**

2 - State

- **Description:** This command gets the device state (stored in its *device_state* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_STATE : State Code
- **Command allowed for:**

3 - Status

- **Description:** This command gets the device status (stored in its *device_status* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
CONST_DEV_STRING : Status description
- **Command allowed for:**



TANGO
Device
Server

Booster Sequence Start User's Guide

RF_PLCBOO Class

**Revision: release_1_0_0 - Author: elattaoui
Implemented in C++**

Introduction:

This class starts the booster sequence and switch(on/off) the local test mode

Class Inheritance:

- Tango::Device_3Impl
 - RF_PLCBOO

Properties:

Device Properties

Property name	Property type	Description
Url	Tango::DEV_STRING	The PLC Server name

Device Properties Default Values:

Property Name	Default Values
Url	No default value

There is no Class properties.

Attributes:

Scalar Attributes			
Attribute name	Data Type	R/W Type	Expert
startRFBoo : Di½marrage de la si½quence RF_BOO	DEV_BOOLEAN	READ_WRITE	No
stopRFBoo : Arret de la si½quence RF_BOO	DEV_BOOLEAN	READ_WRITE	No
localTestMode : Test sur charge	DEV_BOOLEAN	READ_WRITE	No

Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
Init	DEV_VOID	DEV_VOID
State	DEV_VOID	DEV_STATE
Status	DEV_VOID	CONST_DEV_STRING

1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection. After an Init command executed on a device, it is not necessary for client to re-connect to the device. This command first calls the device *delete_device()* method and then execute its *init_device()* method. For C++ device server, all the memory allocated in the *nit_device()* method must be freed in the *delete_device()* method. The language device desctructor automatically calls the *delete_device()* method.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_VOID : none.
- **Command allowed for:**

2 - State

- **Description:** This command gets the device state (stored in its *device_state* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_STATE : State Code
- **Command allowed for:**

3 - Status

- **Description:** This command gets the device status (stored in its *device_status* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
CONST_DEV_STRING : Status description
- **Command allowed for:**

Frame Alert

This document is designed to be viewed using the frames feature. If you see this message, you are using a non-frame-capable web client.
[Link to Non-frame version.](#)



TANGO
Device
Server

Booster Sequence Start Device Commands Description RF_PLCBOO Class

Revision: release_1_0_0 - Author: elattaoui

1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection. After an Init command executed on a device, it is not necessary for client to re-connect to the device.
This command first calls the device *delete_device()* method and then execute its *init_device()* method.
For C++ device server, all the memory allocated in the *init_device()* method must be freed in the *delete_device()* method.
The language device desctructor automatically calls the *delete_device()* method.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_VOID : none.
- **Command allowed for:**

2 - State

- **Description:** This command gets the device state (stored in its *device_state* data member) and returns it to the caller.
- **Argin:**
DEV_VOID : none.
- **Argout:**
DEV_STATE : State Code
- **Command allowed for:**

3 - Status

- **Description:** This command gets the device status (stored in its *device_status* data member) and returns it to the caller.
 - **Argin:**
DEV_VOID : none.
 - **Argout:**
CONST_DEV_STRING : Status description
 - **Command allowed for:**
-

ESRF - Software Engineering Group